

# Important Information About The WaterBoy Floral Watering Machine MODEL # WB M - 16




## INSTRUCTIONS:

- CAREFULLY UNBOX THE WATERBOY**  
Align the holes of the "T" Handle with the holes on the frame. Put the carriage bolts through and tighten up with the lock washers and wing nuts provided. Use pliers to tighten.
- ATTACH THE SINK TO HOSE ADAPTER**  
Unscrew the aerator tip off your sink and screw on the Sink-to-Hose adapter which is found inside the Work Box on top of the WaterBoy.
- FILL THE WATERBOY**  
Attach the Swivel Fitting that's on the end of the ON/OFF Flow Control Valve to the sink. Turn Valve to the open position & turn water on.
- FILLING TIME: 5 MINUTES. WHEN WATERBOY IS FULL**  
A) Shut off water, B) Turn off the valve, C) Unscrew from sink
- ATTACH THE WATER WAND**  
Screw Water Wand to Swivel end of Valve. Keep Valve in OFF position.
- ADJUST THE FLOW**  
Follow the 2 steps demonstrated on the bottom of this page. NOTE: DON'T just open flow valve to full on (too much flow!).

**NOTE:** Hydro Pneumatic Tanks used in Watering Machines are designed for cold to tepid water applications and are not suitable for hot water usage. Hot water will damage the inner rubber diaphragm and WILL void the warranty. In addition, storage of these Watering Machines must be kept away from heat in which the temperature is above 100° degrees and should be stored inside or in areas not subject to direct sun or in temperatures above 100° degrees. Improper storage of Watering Machines will also damage the rubber diaphragm and will void the warranty.

**CAUTION: DO NOT** unscrew the Brass double female swivel off of the shut-off valve or it will leak and warranty will be void.

**CAUTION: DO NOT** Break or Remove seal. Releasing air from top chamber will disable the unit.




This is a 1/4 turn valve. DO NOT force past the off position or valve handle may snap off!



To adjust flow, with valve in the OFF position, use your fingers to PRESS on the Thumb Valve.



Slightly crack the flow valve. Flow starts off as a drip, continue until you adjustment is the way you like it.



Here's how it works!  
Normal water pressure the WaterBoy's unique tank!  
**IMPORTANT: DO NOT** break air cap seal on tank!

PLANT • TEC H<sub>2</sub>O